



# RGB Lasersystems LabView2020 minimal example


## 1. Find virtual COM port number of your laser in windows device manager




## 2. Open *Laser\_COM.vi*



## 3. Select COM port of your laser




#### 4. Start vi



## 5. Control the laser via serial commands (see manual chap 4 *Computer Control*)

Every command must be terminated by termination chars "`\r\n`"

### a. Turn on laser output



### b. Read current temperature

